

Sit-on-top Clamshell seat (high and low models) Installation:

Parts included:

1. 2pcs 20mm M6 flat head screws
2. 4pcs O-rings lanyards
3. 1pc High clamshell seat with quick clip attachments.



Tool needed:

1. #2 Philips head screw driver.

Installation:

1. Remove the existing back band (If applicable) from the seat, by using a Philips head screw driver to remove the 2 anchor screws on the cockpit handles, which the back band strap is fastened through. Then re-screw the 2 screws into the hole anchoring the handle back to the boat.
 - a. **Do not use a drill to undue or screw the boat hardware as high speed can cause heat build-up and cross threading. Hand tools are safer and more accurate.**
2. Using the screw driver, remove the 2 most forward screws in the recess deck fittings holding the bungee cord. These are under tension, so hold the plastic fitting, to keep the bungee from rebounding and shooting the screw off into your surroundings.
3. Use the 2 new longer screws included in the package to reattach the bungee guides to the deck while fitting an O – ring lanyard on the screw, sandwiched between the deck and plastic bungee guide, keeping the O-ring facing the seat.
4. Turn over page to continue installation



5. Move to the cockpit handles and remove the forward screw on each handle and slip the a lanyard under the handle flange with the O-ring facing the seat and re-attach the screw into the original hole and going through the hole in the O-ring lanyard.
6. With the 4 O-rings installed, you can now outfit your seat. The 2 back straps clip to the stern deck O-rings. These straps control the fore and aft position of the seat.
7. The forward straps connect to the cockpit handle O-rings, which control the tilt and tension of the seat back.

